

WHY IS MY WOOD FLOOR SQUEAKING?

MOVEMENT CAUSES SQUEAKS.

FINDING OUT WHY YOUR FLOOR IS MOVING AND SECURING IT TO BE STABLE IS THE BEST WAY TO DIAGNOSE AND FIX A SQUEAK PROBLEM.



SEASONAL MOVEMENT

When the heaters are on, our homes become very dry. Without a humidifier, the wood floors will shrink, which causes squeaks.

SQUEAKY SUBFLOOR

Poor quality, out of level, off-center with joists - there's many factors why your subfloor may be causing squeaks.



FASTENERS

Using the right fastener during installation is the a good way to prevent movement and squeaks. Installers need to pay attention to the fastener length, gauge, nailing schedule, and the pressure settings on their compressor.